






RS Stock No. 808-7030
RS Stock No. 808-7042
RS Stock No. 808-7046

Instruction Leaflet - For Magnifier Lamps

TECHNICAL SPECIFICATIONS			
DESCRIPTION	Compact LED table magnifier lamp	Wide Lens fluorescent magnifier table lamp	Long Reach LED Magnifier Lamp, with extra 5D lens
RS PART NO.s	8087046	8087030	8087042
MANUFACTURER REF.s	LA8093LED/RS/EUK	LA8095RS/EUK	LA8060LED/RS/EUK
VOLTAGES AVAILABLE	220v & 240v, 50Hz	220v & 240v, 50Hz	220v & 240v, 50Hz
MAGNIFIER	100mm(4") diameter lens	175x108mm (7"x4.3") diameter lens	125mm (5") diameter lens - Removable
MAGNIFICATION	1.75x (3 dipotre) & inbuilt 4x (12 dioptre)	1.75x (3 dipotre) & inbuilt 4x (12 dioptre)	Fitted 3 dioptre lens;1.75x mag. & includes 5 dioptre lens;2.25x mag.
SUN PROTECTOR CAP	YES	YES	YES
LIGHT TYPE	30 x White LED mini bulbs = 2w; 6500 Kelvin; Energy efficient; Upto 20,000 Hours of use	1 x 22w circular tube daylight fluorescent 8087049 (LA8095RS/T)	90 x White LED mini bulbs = 8w; 6000-7000 Kelvin; Energy efficient; Upto 20,000 Hours of use
CABLE LENGTH	1.5m	1.5m	1.6m
TABLE CLAMP/BASE	Integral Base	Integral Base	Table Clamp

HOW TO USE	HOW TO USE	HOW TO USE
1. Insert the 220v or 240v plug into a conveniently located electrical socket	1. Insert the 220v or 240v plug into a conveniently located electrical socket	1. Securely fasten the table clamp included to a solid horizontal surface with thicknesses between 12.5 - 62.5mm (0.5 - 2.5"). Ideal for household tables, study desks and work benches
2. Switch the lamp on by using the on/off switch located on top on the base. The lamp is now ready to use.	2. Switch the lamp on by using the on/off switch located on top on the base. The lamp is now ready to use.	2. Insert the stem of the lamp into the clamp hole
3. Adjust your lamp head position to suit your need.	3. Adjust your lamp head position to suit your need.	3. Insert the 220v or 240v plug into a conveniently located electrical socket
		4. Switch the lamp on by using the on/off switch located on top of the head. The lamp is now ready to use.
		5. Adjust your lamp head position to suit your need and tighten the locking nuts as required

	CHANGING THE TUBE	REMOVING THE LENS
		You may wish to remove the lens for cleaning purposes or to replace with the 5 dioptre / 2.25x magnification lens
	1. Switch the lamp off and take the plug out of the electrical socket	1. Please switch the lamp off and remove the plug from the mains socket
	2. Take the transparent tube protector cover off	2. Turn the plastic lens retainer anti-clockwise and carefully remove the lens
	3. Allow the tube to cool off and then remove carefully by unplugging	3. Replace lens and turn the plastic lens retainer clockwise to fix securely into position
	4. Replace with new tube and reposition the tube protector cover	

IMPORTANT! - SAFETY INSTRUCTIONS

WARNING: When using electrical products, important safety precautions must be adhered to in order to reduce the risk of fire, electric shock and personal injury.

PLEASE READ THE FOLLOWING CAREFULLY:

1. Indoor use only:
 - a. Room temperature from -20 to +40 degrees centigrade
 - b. Humidity: Less than or equal to 95%
2. Do not expose the lamp to:
 - a. High temperatures
 - b. Water, steam or damp conditions
 - c. Corrosive, flammable liquids, or gaseous / explosive atmospheres
3. Do not abuse the cord. Never carry the lamp by the cord or pull the cord to disconnect the lamp. Keep the cord away from heat, oil or sharp objects
4. Disconnect your lamp when not in use and when changing tubes
5. Never attempt to disassemble or repair the lamp, unless you are a qualified electrician
6. **CAUTION:** Never leave the magnifier lens unattended in direct sunlight or where light can shine through it - This constitutes a fire hazard!

CE Declaration of Conformity	We declare that this product complies with the Electromagnetic Compatibility Directive and the Low Voltage Directive
------------------------------	--

RS COMPONENTS UK
PO BOX 99
CORBY
NORTHANTS, NN17 9RS
United Kingdom

Tel: +44 (0)8457 201201

Fax: +44 (0)845 8509911

WEB: rswww.com



RoHS Compliant