


Form 434-120613

Part Number	Description
G4BATT32	3.6V Battery For Controller Memory

Description

The G4BATT32 is a kit to replace a discharged memory retention battery on the Opto 22's G4 and M4 Controllers. The battery is designed for easy user replacement.



Features

- Velcro® Mounting for Battery
- Keyed Connector for Solderless Replacement
- Lithium Battery for Long Life
 - Includes Replacement Date Sticker
- Low Self-discharge Rate Allows up to 10 Years Shelf Life Before Installation

Form 434-120613

Specifications

Lithium Battery Operation Life:	2-5 years
Shelf Life:	10 years
Voltage:	3 volts

Connections

PIN:

1. Red +3V
2. Keying Plug
3. Unused
4. Black Ground



Installation: M4 or G4LC32SX Controller

Remove the battery connection to the mother board and replace it with the new battery.

Installation: G4LC32 Controller

CAUTION: When you change the battery, the strategy and all persistent data will be lost. Make sure you have the strategy available so you can download it after the new battery is in place.

1. Locate the strategy and make sure it is available for downloading.
2. Remove the power supply and any communication cable connections.
3. Remove the four screws attaching the communications board to the controller.
4. Gently pull off the communications board to access the mother board.
5. Remove the battery connection to the mother board and replace it with the new battery.
6. Reattach the communications board and all cables. Reapply power.
7. Download the strategy to the controller.




Form 434-120613

Installation: SNAP-LCM4 Controller

CAUTION: When you change the battery, the strategy and all persistent data will be lost. Make sure you have the strategy available so you can download it after the new battery is in place.

1. Locate the OptoControl strategy and make sure it is available for downloading.
2. Turn off power to the controller and disconnect communication cables from COM0, COM1, COM2, and COM3.
3. Remove the cover with the SNAP-LCM4 label.
4. Carefully slide out the two circuit boards.
5. Replace the battery.
6. Carefully slide the two circuit boards back into place and replace the cover.
7. Reattach the communication cables. Reapply power.
8. Download the strategy to the controller.



More About Opto 22

Products

Opto 22 develops and manufactures reliable, flexible, easy-to-use hardware and software products for industrial automation, energy management, remote monitoring, and data acquisition applications.

OptoEMU Energy Management System

The easy-to-use OptoEMU Sensor monitors electrical energy use in your facility and delivers detailed, real-time data you can see and analyze. The Sensor can monitor energy data from pulsing meters, electrical panels or subpanels, and equipment. View energy data online using a software service or incorporate the data into your control system for complete energy management.

SNAP PAC System

Designed to simplify the typically complex process of selecting and applying an automation system, the SNAP PAC System consists of four integrated components:

- SNAP PAC controllers
- PAC Project™ Software Suite
- SNAP PAC brains
- SNAP I/O™

SNAP PAC Controllers

Programmable automation controllers (PACs) are multifunctional, modular controllers based on open standards.

Opto 22 has been manufacturing PACs for over two decades. The standalone SNAP PAC S-series and the rack-mounted SNAP PAC R-series both handle a wide range of digital, analog, and serial functions for data collection, remote monitoring, process control, and discrete and hybrid manufacturing.

SNAP PACs are based on open Ethernet and Internet Protocol (IP) standards, so you can build or extend a system easily, without the expense and limitations of proprietary networks and protocols.

PAC Project Software Suite

Opto 22's PAC Project Software Suite provides full-featured, cost-effective control programming, HMI (human machine interface) development and runtime, OPC server, and database connectivity software for your SNAP PAC System.

Control programming includes both easy-to-learn flowcharts and optional scripting. Commands are in plain English; variables and I/O point names are fully descriptive.

PAC Project Basic offers control and HMI tools and is free for download on our website, www.opto22.com. PAC Project Professional, available for separate purchase, adds

OptoOPCServer, OptoDataLink, options for controller redundancy or segmented networking, and support for legacy Opto 22 serial *mistic*™ I/O units.

SNAP PAC Brains

While SNAP PAC controllers provide central control and data distribution, SNAP PAC brains provide distributed intelligence for I/O processing and communications. Brains offer analog, digital, and serial functions, including thermocouple linearization; PID loop control; and optional high-speed digital counting (up to 20 kHz), quadrature counting, TPO, and pulse generation and measurement.

SNAP I/O

I/O provides the local connection to sensors and equipment. Opto 22 SNAP I/O offers 1 to 32 points of reliable I/O per module, depending on the type of module and your needs.

Analog, digital, and serial modules are all mixed on the same mounting rack and controlled by the same processor (SNAP PAC brain or rack-mounted controller).

Quality

Founded in 1974, Opto 22 has established a worldwide reputation for high-quality products. All are made in the U.S.A. at our manufacturing facility in Temecula, California. Because we do no statistical testing and each part is tested twice before leaving our factory, we can guarantee most solid-state relays and optically isolated I/O modules for life.

Free Product Support

Opto 22's California-based Product Support Group offers free, comprehensive technical support for Opto 22 products. Our staff of support engineers represents decades of training and experience. Support is available in English and Spanish by phone or email, Monday–Friday, 7 a.m. to 5 p.m. PST.

Additional support is always available on our website: how-to videos, OptoKnowledgeBase, self-training guide, troubleshooting and user's guides, and OptoForums.

In addition, hands-on training is available for free at our Temecula, California headquarters, and you can [register online](#).

Purchasing Opto 22 Products

Opto 22 products are sold directly and through a worldwide network of distributors, partners, and system integrators. For more information, contact Opto 22 headquarters at 800-321-6786 or 951-695-3000, or visit our website at www.opto22.com.

www.opto22.com